
COND. SHEAR WRENCH

INSTRUCTION MANUAL No.1310



MODEL

US-221EZ / US-222EZ USS-221EZ / USS-222EZ



ACAUTION

Read and fully understand all the instructions before use.

Keep this manual in designated place for easy and quick reference.

The models mentioned on this manual are designed for use outside Japan.

Warranty shall be void if above mentioned models are use in Japan.

TONE CO., LTD.

PREFACE

Thank you for purchasing SHEAR WRENCH .

- Upon receipt, check and confirm the following:
- Check any transport damages.
- Check for any loose or lost screws and bolts.
- Check the model as per order.
- Check all the accessories are contained.

If any problems are found, contact your distributor.


- Read this instruction manual carefully before use.
 Full understanding of manual is essential to prevent personal injury or malfunction.
- Keep this manual in a bag attached to the back of metal case lid for easy and guick reference.
- If manual or warning label is lost or becomes illegible, or if additional manual is required, contact your distributor.

If you have any questions about the products or the contents of this instruction manual, contact your distributor.

This manual is only applicable to outside Japan.

SAFETY INSTRUCTION

This manual specifies three (3) basic safety instructions:



■ Instructions are classified by degree of risk and described as follows:

⚠ DANGER	Danger is used to indicate threatening dangerous or unsafe practices which could immediately result in severe personal injury or death in the worst case.
▲ WARNING	Warning is used to indicate hazardous or unsafe practices which could result in severe personal injury or death in the worst occasion.
A CAUTION	Caution is used to indicate hazardous or unsafe practices which could result in personal injury or product or property damage.

Even if the risk is classified as A CAUTION , risk could become more serious result depending on conditions. Make sure to follow all instructions when using.

TABLE OF CONTENTS

1. GENERAL SAFETY INSTRUCTIONS	4
2. APPLICATION ·····	4
3. APRECAUTIONS FOR USE	
4. PART NAME ······	11
5. FEATURES ·····	12
6. BEFORE USE ·····	13
7. OPERATING PROCEDURE ·····	14
8. CHANGING SOCKET ·····	16
9. INSPECTION & MAINTENANCE ·····	20
10. SPECIFICATIONS ·····	22
11. AFTERSALES SERVICE ······	23

1. GENERAL SAFETY INSTRUCTIONS

MARNING

When using electric tools, basic safety precautions, including the following, should always be followed to reduce the risk of fire, electric shock and personal injury. Read all these instructions before operating this product and keep these instructions.

SAVE THESE INSTRUCTIONS

1) Work area

- a) Keep work area clean and well lit. Cluttered and dark areas invite accidents
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust of fumes.
- c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2) Electrical safety

- a) Power tool plugs must match the outlet. Never modify the plug in any way.
 Do not use any adapter plugs with earthed (grounded) power tools.
 Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.

3) Personal safety

- a) Stay alert, watch what you are doing and use common sense
 when operating a power tool. Do not use a power tool while you are tired
 or under the influence of drugs, alcohol or medication.
 A moment of inattention while operating power tools may result in serious
 personal injury.
- b) Use safety equipment. Always wear eye protection. Safety equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Avoid accidental starting. Ensure the switch is in the off position before plugging in. Carrying power tools with your finger on the switch or plugging in power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on.
 A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) Do not overreach. Keep proper footing and balance at all times.

 This enables better control of the power tool in unexpected situations.
- f) Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.
- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust related hazards.

4) Power tool use and care

- a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off.
 Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c) Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tools operation. If damaged, have the power tool repaired before use.
 Many accidents are caused by poorly maintained power tools.
- f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) Use the power tool, accessories and tool bits etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from intended could result in a hazardous situation.

5) Service

 a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

- 6 -

2. APPLICATION

■ **SHEAR WRENCH** is an electric tool for tightening Tension Control Bolt/Nut/Washer assemblies.

3. PRECAUTIONS FOR USE

■ To prevent accidents, personal injury and etc, read and follow all instructions listed below

⚠ DANGER

- Beware of electric shock when operating at high place.
 - O Failure to follow this instruction may result in fall down accidents.

MARNING

		<u>Z!\</u> WARNING
•	Ве	ware of electric shock.
	0	Never use the wrench under rainy or snowy condition.
	0	Never touch the plug with wet hands.
		ilure to follow this instruction may result in electric shock, fire or ectric leakage.
•	Ele	ectric cord must be regularly inspected.
	0	Stop using the wrench if there is a problem with the electric cord.
	0	Contact your distributor for repair.
		ilure to follow this instruction may result in electric shock or electric akage.
•		ver use the wrench around the place where gasoline, gas, nner, benzene, etc., are stored.
	0	Do not use the wrench around flammable substances to avoid the accidental fire caused by the spark out of the electric motor.
•	Ве	ware of fall down accidents when working at a high place.
	0	Wear safety belt
	0	Provide safety net or canvas as safe guarding against falling items.
	0	Confirm that no one is underneath the working site before operation.
	0	Stop operation when physically or mentally tired.
	Fa	ilure to follow these instructions may result in fall down accidents.
•	Av	oid overloading.
	0	Use the wrench and its accessories within the rated specifications.

wrenches, accidents or personal injury.

Overloaded wrench and its accessories may result in malfunction of the

Properly install sockets as described in this manual.				
0	Incomplete installation may result in accidents and personal injury.			
	See "CHANGING SOCKETS" on page 19.			

Avoid accidental Starting.

- O Ensure that the switch is in the off-position before plugging into power source.
- O Never carrying the wrench with your fingers on the switch when the plug is connected to power source.

Disconnect the plug from the power source when:

- O Not in use.
- Changing accessories.
- O Inspection and maintenance.
- O or other danger is foreseen.

Failure to follow these instructions may result in accidental starting and personal injury.

Do not disassemble or modify the wrench.

- O Disassembly or modification made by unauthorized personnel may result in malfunction or personal injury.
- O Disassembly & Re-assembly work is permitted for the following expendables: Inner Socket, Outer Socket and Carbon Brushes.

Store the wrench in the metal case and keep it at the designated place when not in use.

O Store wrench in lockable dry location to keep any unauthorized personnel away.


Failure to follow this instruction may result in malfunction or accidents.



	 Immediately stop using the wrench and disconnect the plug when unusual sound, vibration or smell is detected. 					
0	Contact your distributor immediately.					
Fai	lure to follow this instruction may result in serious injury.					
• Co	ntact your distributor for repair service.					
0	Repair work should only be carried out by a qualified serviceman.					
0	Repair work done by an inexperienced person may cause accidents, injury or malfunction.					
• Ch	eck the following items before operation.					
0	Check for any deformation, crack or damage on the wrench body, sockets, electric cord, plug and etc.					
0	Do not use the wrench if any problem are found on items listed above.					
0	Make sure that socket assembly is correctly installed on the wrench.					
Use	e appropriate power source as indicated on the rating plate.					
Fai	lure to follow this instruction may result in fire or burn accidents.					
	 Immediately check the wrench when it is dropped down or banged. 					
0	Check for deformation, crack, damage and other abnormality. Stop using the wrench if any abnormality is found.					
Со	ntinued use of fault wrench may result in accidents and personal injury.					

MARNING

- Check if leakage breaker is available together with earth connection.
 - O Recommended leakage breaker: Rating capacity at 15mA and acting time below 0.1sec
- Grounding (Earth Connection) is always required.
 - O Supplied tool has no double insulation structure, hence tool must be earthed.
- Do not connect grounding (earth) lead to gas pipe
- If extension cable is used, apply those with earth and 3-P cable.
 - One cable must be adapted as earth cord and must be connected to the earth terminal on the tool.
 - O 2 core cable without earth cord might cause electric shock.



⚠ CAUTION

Ke	● Keep work area clean.					
0	Cluttered areas and benches invite accidents.					
Ke	ep children away.					
0	Do not let children touch the wrench and electric cord. All visitors should be kept away from work area.					
Se	cure work area.					
0 0	Keep body stance balanced and firmed. Never wrap the electric cord around something. Keep work area well lit.					
Us	e suitable model for each application.					
0	Do not use wrench beyond its rated specifications. Do not use wrench for purpose not intended.					
• Dr	ess properly.					
0	Always wear gloves and non-skid footwear when operating outdoor. Always wear safety helmet.					
	e genuine accessories or attachments manufactured by neda Metal Industries, Ltd.					
	not connect multiple plugs to a single outlet by using multiple tlet adaptors.					
0	Over current may cause fire, accidents or malfunction.					
Do	not abuse the electric cord.					
0	Never use the electric cord for carrying, pulling, or unplugging the power.					
0	Keep the electric cord away from heat, oil, sharp edges or moving parts.					


ACAUTION

- Keep electric motor well ventilated.
 - O Do not put any foreign materials into the vent.
 - O Do not block exhaust vent.
- Maintain wrench.
 - O Keep wrench handle clean, dry and free of oil or grease.
- Provide leakage breaker as a shock guard for each wrench.
- When applying extension cord, select shorter extension units than specified below depending on the cross section.

Nominal conducting		Max. Length		
cable cross section		115V	220V	
	1.25mm ²	10m	20m	
H07RN-F	2.0mm ²	20m	40m	
	3.5mm ²	30m	60m	
AWG 14		50ft	100ft	
AWG 12		80ft	160ft	
AWG 10		130ft	260ft	

- O Using extension cord more than Maximum Length may result in malfunction or breakdown due to performance drop of the wrench.
- Use attached connector when using extension cord.
- Observe local laws and rules concerning noise level.

4. PART NAME



Model	Accessory	
	Inner Socket	
US-221EZ	Outer Socket	
US-222EZ	(-) Driver	
USS-221EZ	Connector (only for 220V)	
USS-222EZ	Metal Case	
	Instruction Manual	

Contact your distributor for other available sockets and accessories.

5. FEATURES

• Short-nosed Corner Type Shear Wrench.

6. BEFORE USE

MARNING

- Check followings before connecting the plug into power source.
 - O Accidental starting invites personal injury.
- 1. Check for any deformation, crack or damage on wrench body, socket, electric cord, etc.

Do not use wrench if any problem is found on items listed above.

2. Make sure to use commercial power supply.

Use appropriate power source as indicated on the rating plate.

- 3. Make sure that socket assembly is correctly installed on the wrench.
- 4. Make sure that set screws are securely fastened.


Loose installation may result in accidents and personal injury.

See "CHANGING SOCKETS" on page 19.


7. OPERATING PROCEDURE

CAUTION


 Snug tight using snug tightening wrench like SNUG MASTER is required before using SHEAR WRENCH.




(1) Slide Inner Socket over the bolt pintail (Fig 4).




- (2) Slide Outer Socket over the nut (Fig 5).
 - Slightly turn Internal Gear when slide over is difficult.




(3) Squeeze trigger switch to start tightening (Fig 6).




(4) Rotating speed gradually shows down as the tightening proceeds, then bolt pintail shears off when designated torque is reached (Fig 7).



(5) When tightening is completed, remove wrench from bolt/nut assembly. Sheared-off bolt pintail remains in Inner Socket (Fig 8).



(6) Push Ejector Knob to eject bolt pintail (Fig 9). Keep pintail in designated bag.




/ WARNING

- Keep others a safe distance from work area.
 - O Do not throw pintail away. Collect pintail in designate bag during operation.

Failure to follow this instruction may result in accidents and personal injury.

8. CHANGING SOCKETS

Remove the spirolox from the wrench body by using (-) driver and then remove the outer socket, thrust metal and inner socket from the wrench body. (Fig.10)




- ② Prepare outer and inner-sockets of the right sizes suitable for the size of bolt to be tightened.
- Example: Use our US series socket for 7/8" to 7/8" bolts.
- 3 Slide the inner socket into the inner socket holder and then slide the thrust metal over the inner socket. (Fig 11)
- Mount the outer socket on the internal gear to remove the gap between the outer socket and the internal gear. (Fig.11) And then, securely fix the inner & outer socket assembly on the wrench body by the spirolox.

MARNING

■ There should be no gap between the socket assembly and the wrench.

The gap invites accidents or breakage of the sockets or the wrench body.



9. INSPECTION & MAINTENANCE


MARNING

- Disconnect plug from power source before inspection and maintenance.
 - O Accidental starting invites serious injury.
- Replace the inner socket when sheared bolt pintail is came off the inner socket without pushing the ejector knob.
 - O There is a risk of unexpected bolt pintail ejection when inner drive of the inner socket is worn down. The inner socket must be immediately replaced.


Failure to follow this instruction may result in serious accidents and injury.

- (1) Clean dust and debris from the sockets periodically.
- (2) Use only a damp cloth to clean your wrench and sockets since certain cleaning agents and solvents are harmful to those parts. Some of these include: benzene, thinner, gasoline and etc.
- (3) Never put solvents into the exhaust vent.
- (4) Store wrench in the metal case after operation and keep it dry.
- (5) Ejector pin must be regularly inspected and replaced when it wears down. Sheared bolt pintail will not be ejected from inner socket with worn ejector pin.

- (6) Carbon brush must be regularly inspected and replaced with the new genuine carbon brush when brush length becomes less than 1/4" (Fig 16).
 - *Carbon brushes are placed in two positions.
 - *Indicate the wrench model when carbon brushes are needed because carbon brush differs from model to model.



(7) Replace carbon brush as shown in the following Fig 14.



(8) Overhaul must be carried out every 6 months or 30,000 tightening, whichever comes first. Contact your distributor for overhaul.

10. SPECIFICATIONS

Model	US-221EZ	US-222EZ	USS-221EZ	USS-222EZ	
Frequency	50-60Hz				
Voltage	115V	220V	115V	220V	
(Single Phase)	1101	2201	1101		
Max Current	13.5A	6.5A	13.5A	6.5A	
Rated Power		135	50W		
Rated	735N⋅m				
Max Torque	540lbf•ft				
Rated	15min ⁻¹ 13min ⁻¹		ain ⁻¹		
No-load Speed			Tomin		
Sound Pressure Level	84dB(A)				
Sound Power Level	95dB(A)				
Vibration Level	2.5m/s² or below				
Weight	7.0kg 8.9kg				
Insulation Class	Class I (Single Insulation)				

• Weight excludes socket & cord.

Model Adaptable Bolt		US-221EZ	US-222EZ	USS-221EZ	USS-222EZ
	M16	0	0	0	0
S10T	M20	0	0	0	0
	M22	0	0	0	0
A325	5/8"	0	0	0	0
A325 A490	3/4"	0	0	0	0
A490	7/8"	0	0	0	0

11. AFTER SALES SERVICE

- Contact your distributor for available services.
- Provide model, serial number, date of purchase and details of failure when contacting your distributor.

ACAUTION

 Do not use wrench when malfunction, deficiency in wrenches' performance, personal injury or property loss is foreseen.

If possible, prepare backup wrenches beforehand.

MEMO

MEMO



TONE CO., LTD.

1-57, MINATOMACHI 2-CHOME, NANIWA-KU, OSAKA 556-0017, JAPAN,

Web Site: http://www.tonetool.co.jp e-mail: overseas@tonetool.co.jp

Specifications and the design are subject to change without notice.